




**Randall M. German Honorary Symposium on
Sintering and Powder-Based Materials
141st TMS Annual Meeting & Exhibition**

Novel Amalgams for in-Space Parts Fabrication

Calvin Cochran – Hendrix College

James R. Van Hoose – Siemens Corporation

Richard N. Grugel – Marshall Space Flight Center




Premise

- **Replacement parts will likely be necessary during extended deep space missions.**
 - **Repair parts increase vehicle weight and take up precious cargo space**
 - **What will break cannot be anticipated**
 - **Fabricating parts can include complicated procedures**
 - Handling and pouring of hot liquid metal**
 - Complicated machining and fluid handling**

Amalgam

- **Amalgam: An alloy of mercury with at least one other metal.**
- **Amalgams are based on a peritectic reaction:**



Dental amalgams are well-understood and have an established application.

Amalgam Considerations



- Room temperature processing
- Corrosion resistant
- Minimum: power consumption, crew interaction, final finishing, and mass/volume consumption
- Moldable
- Net-shape part (no shrinkage or additional machining)
- No fluid handling issues (hot liquid metal)

Amalgams have potential for fabricating parts during deep space missions.

Sche
durin

S
g pa
mis


using amalgams



Amalgam Disadvantages

Mercury, which is toxic, is typically used



Amalgams have low tensile strengths (~10% of compression)



Cu-Ag-Sn Amalgam Powder
Consisting of Atomized Spheres
and Lathe-cut Particles

Solutions to Disadvantages

Substitute Ga-In
liquid for Hg



Include high-strength
steel fibers with
commercial Ag-Sn-Cu
powder



Research Objective

Can Ga-In liquid substitute for Hg?



Will the inclusion of steel fibers improve the mechanical properties of amalgams?

SEM micrographs of processed samples with and without fibers

Dense fully
reacted
amalgam
with no
porosity in
both cases.




Color key:
Turquoise = tin,
Indium = green,
Silver = purple,
Gallium = red,
Iron/steel = grey,
Copper = orange




Fracture Surfaces


A typical
amalgam
(no fibers)
fracture
surface



A fracture
surface of
an
amalgam
with steel
fibers




A phase
map
showing
the
distribution
of steel
fibers




Mechanical Testing: Load to Failure

A comparison of the load to failure (crush) strength of amalgams without fibers and those with.




Samples with included steel fibers performed better

Mechanical Testing: Diametrical Tensile Strength




Samples with included steel fibers again performed better


Role of Steel Fibers



Micrograph of a broken steel fiber (center) in the amalgam matrix.



Higher magnification showing the dimpled fracture surface of the steel fiber surrounded by reaction products.



Elemental phase map showing the extent of steel (gray color) after necking, ~36% reduction in area.

Mechanical properties increase due to the steel wires inherent strength, its bonding with the matrix, and subsequent plastic deformation prior to failure.

Conclusions

- **Sound amalgams can be fabricated by substituting Ga-In liquid for mercury; Cu-coated steel fibers bond well with the amalgam components.**
- **Inclusion of steel fibers significantly improved mechanical properties.**
- **An application scenario utilizing amalgams for in-space parts fabrication and repair was suggested.**
- **Procedure and materials need to be optimized.**

Acknowledgments

Appreciation is expressed to Greg Jerman, Ms. Lisa Sharff, Craig Stafford, and Dr. Preston McGill for their timely assistance. Support from the Materials and Processing Laboratory of the Marshall Space Flight Center is also greatly acknowledged.



**Randall M. German Honorary Symposium on
Sintering and Powder-Based Materials
141st TMS Annual Meeting & Exhibition**

Backup Slides


Outline

- **Introduction**
 - **Premise**
- **Amalgams**
 - **Advantages/Disadvantages/Solutions**
 - **Scenario applications**
- **Experiment**
 - **Objective**
 - **Process**
 - **Results: Microstructures, Fracture Surfaces, Mechanical Testing, Modeling**
- **Future work and Conclusions**

Molding

In order to create spare parts, molds can be made by a Fused Deposition Modeling machine and filled with amalgams.


Examples of
shapes made by
a FDM



Fused Deposition
Modeling machine




The Process

- Determine and weigh out amalgam components.
- Place components in plastic capsule and mechanically mix.
- Insert newly reacted amalgam in quartz cylinder between two quartz pistons, compress in clamp, and leave overnight.
- Mechanically test sample using a laboratory press to determine load to failure or diametrical tensile strength.
- Evaluate microstructure.




Amalgam Reactions: Intermetallic Compounds

SEM phase maps and extracted spectra can be used to predict compounds formed within amalgams.



Cu-Ga phase diagram

Mechanical Testing: DTS



Samples with included steel fibers performed better

The rule-of-mixtures was applied to predict optimal tensile strength. The formula is as follows:



$$\delta_{co} = \chi V_f \delta_f + V_m \delta_m$$

Note that δ_{co} , δ_f , and δ_m are the ultimate strengths of the amalgam, fibers, and matrix(everything but the fibers), respectively. Note that V_f and V_m are the volume fractions of the fiber and matrix and that χ is a constant which considers fiber orientation and length factors.

Sample Preparation Problems

**Good processing with
good microstructure
resulting in good
properties. Well coated
fibers.**

**'Crumbly' lack of
bonding between
fibers and powder,
due to insufficient
liquid**



**'Bunched'
fibers, poor
mixing
precludes
any reaction**



Future work

Materials and processing parameters need to be optimized in order to maximize material properties. These include, for example:

- **Fiber lengths and volume fractions**
- **Mixing techniques**
- **Reaction/setting time (not too fast)**

Steps toward preparing larger samples should also be taken.